



## INSTRUCTIONS MANUAL AND INSTALLATION



## GRILLS

Models:

GR 1, GR 2, GR 3



# CONTENTS

|   |                               |
|---|-------------------------------|
| <b>1. CE CERTIFICATION</b>                              | <b>2</b>                      |
| <b>2. WARRANTY</b>                                      | ¡ERROR! MARCADOR NO DEFINIDO. |
| <b>3. INSTRUCTIONS FOR INSTALLATION AND MAINTENANCE</b> | ¡ERROR! MARCADOR NO DEFINIDO. |
| <b>4. INSTRUCTIONS FOR USE</b>                          | ¡ERROR! MARCADOR NO DEFINIDO. |
| <b>5. FREQUENTLY ASKED QUESTIONS</b>                    | ¡ERROR! MARCADOR NO DEFINIDO. |

## 1. CE CERTIFICATION

### **DECLARACIÓN UE DE CONFORMIDAD EU DECLARATION OF CONFORMITY**

Directiva(s) del Consejo con la(s) que se declara conformidad:

*Council Directive(s) to which conformity is declared:*

**DC 2014/35/EU + DC 2014/30/EU + DC 2011/65/EU**

Aplicación de las Normas:

*Application of the Standards:*

**UNE-EN 60335-1:2012 + AC:2014 + A11:2014 + A13:2017 + A14:2014 + A2:2020 + A1:2020; UNE-EN 60335-2-42:2004 + Corr:2007 + A1:2008 + A11:2012; UNE-EN 55014-1:2017 + A11:2021; UNE-EN 55014-2:2015; UNE-EN 61000-3-2:2014; UNE-EN 61000-3-3:2013 + A1:2020**

*Fabricante / Manufacturer's name* **FM CALEFACCIÓN S.L.  
CIF: B-14343594**

*Dirección / Manufacturer's address:* **CTRA. de Rute km.2.700, C.P.:14900, Lucena,  
Cordoba, Spain**

*Tipo de aparato / Type of device:* **HORNO / OVEN**

*Marca / Trade.:* **FM CALEFACCIÓN**

*Modelo / Model no.:* **GR 1 / GR 2 / GR 3**

**Nosotros, los abajo firmantes, declaramos bajo nuestra exclusiva responsabilidad que el equipo especificado cumple con la(s) Directiva(s) y Norma(s) mencionadas**

**We, the undersigned, hereby declare under our sole responsibility that the specified equipment is in conformity with the above Directive(s) and Standard(s)**



*Lugar / Place:* **Lucena**

(Firma / Signature)

*Fecha:* **01/01/2021**

**B-14343594**  
(Nombre / Full name)



## 2. WARRANTY

The warranty period is **12 months** from the date of the purchase of the unit.

The warranty does not cover damages to the glass, lamps, door seals, damage to the insulating material or damage caused by improper installation or maintenance, lack of maintenance, improper repair or misuse.

To process the repair of a unit under warranty or for any other query, please contact your distributor and refer to the following description table.

|                              |                             |
|------------------------------|-----------------------------|
| <b>Distributor:</b>          | <b>Destination country:</b> |
| <b>Unit model:</b>           | <b>Serial number:</b>       |
| <b>Name:</b>                 | <b>Date of the request:</b> |
| <b>Fault description:</b>    |                             |
| <b>Address:</b>              |                             |
| <b>Contact phone number:</b> | <b>Working hours:</b>       |




**Improper adjustment, installation, service or maintenance of the unit may lead to damages to the goods or persons. For this reason, please, read this manual thoroughly before starting the unit.**

### 3. INSTRUCTIONS FOR INSTALLATION AND MAINTENANCE

- **Placement distances**

The distances from the unit to adjacent elements should be as shown in the diagram. If there are heat sources or combustible elements, the safety distance should be at least 500 mm.

Locate the appliance under the ventilation hood, to eliminate possible vapors and bad smells.



- **Electrical installation**

Make sure that the network characteristics correspond to those described in the technical characteristics of each device.

A separate power supply line protected by a magneto-thermal circuit breaker of a suitable gauge is recommended, as well as fixed mains connection for the connection of models not equipped with schucko.



## 4. INSTRUCTIONS OF USE

- **User instructions**

Read this manual carefully before starting to work with the unit. Keep it for future reference and consult an authorized service center when you need technical assistance.

The appliance is designed for use in the baking of regeneration of fresh or frozen bakery and pastry products, with a maximum temperature regulation range of 250° C.

We also recommend that you preheat the appliance to working temperature for about 20 minutes, which guarantees a better product finish.

- **First use of the device**

Remove the outer protective plastic film. If any glue residue remains, use a suitable solvent and then clean with soap and rinse.

The inside of the chamber and trays should be cleaned with soap and water and then cycled at 80°C for 30 minutes.

Warning: never use products that may be aggressive or acidic, as this could damage the device.

Warning: always disconnect the power supply and wait until the appliance is cold before carrying out maintenance or cleaning operations.

- **Use for cooking**

**Warnings:**

- Prevent children from having access to the device.
- The product must be handled and installed by qualified personnel.
- Original spare parts must be used for any repairs.
- The product should not be cleaned with abrasive products that may damage the surfaces.
- Water jet should not be applied after use.
- During use, the external parts of the device may reach high temperatures, so the use of thermal gloves is recommended during handling.
- Do not strike the refractory base or subject it to sudden temperature changes.

**Control panel**





Tabla 1

| Id | Description                         | Versions     |
|----|-------------------------------------|--------------|
| 1  | Temperature LED                     | GR 1/ GR 1 L |
| 2  | Temperature control knob            | GR 1/ GR 1 L |
| 3  | Left side temperature LED           | GR 2/ GR 2 L |
| 4  | Right side temperature LED          | GR 2/ GR 2 L |
| 5  | Left side temperature control knob  | GR 2/ GR 2 L |
| 6  | Right side temperature control knob | GR 2/ GR 2 L |


The user can regulate the temperature with the knob shown (see table 1), in a range of 50 - 250 °C. Whenever the unit is heating by resistance, the LED next to this knob will light up.

Temperature control knob



- **Adjustment of cover hardness**

It is possible to adjust the hardness of the upper cover of the appliance. For this purpose, an allen head screw is located on the rear of the device (see following picture). Using the tool provided for this purpose, tighten the screw to stiffen the movement of the cover, or loosen the screw to make the movement of the cover softer.



*Cover hardness adjustment screw*

## **5. FREQUENTLY ASKED QUESTIONS**





When you have finished working with the unit, disconnect it from the mains, wait for it to cool down and clean the chamber with soap and water. Then rinse and dry the unit, leaving the door open for about 30 minutes.

**DO NOT SPRAY WATER DIRECTLY ON THE DEVICE, AS THIS MAY DAMAGE COMPONENTS**

These are the most common failures that have been asked by our clients:

*Tabla 2*

| <b>FAILURE</b>                | <b>CAUSE</b>                     | <b>SOLUTION</b>                  |
|-------------------------------|----------------------------------|----------------------------------|
| Device does not turn on       | Lack of mains voltage            | Check mains voltage              |
|                               | Inadecquate network connection   | Check network connection         |
|                               | Thermostat does not work         | Contact a specialized technician |
|                               | LED light does not work          | Contact a specialized technician |
| Device does not cook properly | Resistor does not work           | Contact a specialized technician |
|                               | Thermostat does not work         | Contact a specialized technician |
|                               | Poor gasket placement            | Contact a specialized technician |
|                               | Door mechanism out of adjustment | Contact a specialized technician |
|                               |                                  | Contact a specialized technician |
|                               | Lamp is not screwed in correctly | Check bushing and screw in       |
|                               | Blown lamp                       | Substitute lamp                  |











**FM CALEFACCIÓN S.L.**  
**B-14343594**

Carretera de Rute, km. 2'700  
14900 Lucena (Córdoba)  
[www.fmindustrial.es](http://www.fmindustrial.es)